

Programming of the RCs 3x series with C-API or BODAS-design

The powerful 3x series BODAS RC control units from Rexroth offer a variety of functions and connection options. Learn how to effectively use the software and hardware features and implement your individual requirements with C-API or BODAS-design.

CONTENTS

- Knowing and defining different input/outputs uses and configurations
- Programming with API based on the sample application
- Knowing and using control system safety functions
- Creating a project-specific diagnosis interface for BODAS-service

Video Links

- | | |
|--|---|
| → 01. Functional Safety-HW-Category | → 22. Input Configuration |
| → 02. Functional Safety-Diagnostic Coverage | → 23. Input Reading |
| → 03. Functional Safety Mean time to dangerous failure | → 24. Input Monitoring |
| → 04. Functional Safety blocks | → 25. Input INEXT |
| → 05. Electrical Schematic | → 26. Output general |
| → 06. Eclipse Overview | → 27. Output OUT Configuration |
| → 07. BODAS-design Overview | → 28. Output OUT |
| → 08. API Help File | → 29. Output OUT Monitoring |
| → 09. BODAS-service – Configurator | → 30. Output OUTEXT |
| → 10. BODAS-service - Configurator process values | → 31. Output SAFOUT Overview |
| → 11. BODAS-service - Configurator parameters | → 32. Output SAFOUT Configuration |
| → 12. BODAS-service - Configurator errors | → 33. Output SAFOUT |
| → 13. System Initialize | → 34. Output SAFOUT Monitoring |
| → 14. System Trigger Watchdog | → 35. EEPROM Overview |
| → 15. System Measure Run Time | → 36. EEPROM Store Values |
| → 16. System Measure Internal Voltages | → 37. EEPROM Read values |
| → 17. CAN Overview | → 38. Power On State Machine |
| → 18. CAN - Transmit Databox | → 39. Emergency Stop |
| → 19. CAN Recieve Databox | → 40. Monitor Startup Checks |
| → 20. CAN Send Data, Recieve Data | → 41. Monitor Cyclic Checks |
| → 21. Channel Naming | |